



Corporate Office:
10 N. Industrial Drive
Monett Mo. 65708
Phone: 800-798-0119
Fax: 417-235-8661

Hollister
417-337-5095

Joplin
417-623-3384

Springfield
417-866-2222

Topeka
785-862-8368

Inflatable Set Up and Tear Down

How to set up:

1. Check ground for a flat level surface void of any rocks, sticks, pine cones, etc. Anything that may puncture the bottom of the Inflatable must be removed from the area.
2. Check height clearance for trees, powerlines, or overhead obstructions.
3. Tarps should be placed under all Inflatables as added protection to help prevent puncture. (Never operate the Inflatable on a hard surface without under padding, i.e. tarp.)
4. Unroll the Inflatable in the direction you wish the Inflatable to face.
5. Unfold and attach the blower(s) to the "Port" (extended air hose/blower tube). The Port is generally located in the very back or on the sides of the Inflatable.
6. Tie off any additional Ports by turning the material clockwise and tying the Port to itself. Rope can be used to close off additional Ports. Some Inflatables allow you to tuck away additional ports.
7. Close ALL Velcro/Zipper compartments.
8. Attach heavy extension cord(s) from power source. Designate one 20 amp for each blower. Generally, this equates to one 110-volt outlet for each blower. Use 12 gauge or heavier extension cord(s) that extend **No More** than 100 feet from the inflatable to the power source. The lower the gauge number, the thicker the cord. Most household/garden extension cords are 16 gauge, **Not Sufficient Enough**, and can harm the blower; thereby reducing the air source to the inflatable.
9. Turn the power on. Some blowers have an On/Off switch located on the blower. While the inflatable inflates – Check to make sure no air is escaping vents or ports.
10. Check to make sure the Port (air hose) leading to the blower is not twisted.
11. Secure the inflatable by staking the unit on all 4 corners. Drive stakes halfway in at a 45-degree angle away from the inflatable. For larger inflatables, tie-outs will need to be staked.

How to Takedown

1. Check for any loose items left on the inflatable. Sweep or vacuum where appropriate.
2. All guests should be clear of Inflatable. Sweep or vacuum where appropriate.
3. All guests should be clear of inflatable, including: stake, flagging, weight bags, etc.
4. Turn off or unplug blower and disconnect the blower from the inflatable.
5. Open all Velcro/zipper flaps, vents and ports to allow air to escape and the inflatable to deflate. Deflation time varies, anywhere from 10 – 20 minutes or more.



Corporate Office:
10 N. Industrial Drive
Monett Mo. 65708
Phone: 800-798-0119
Fax: 417-235-8661

Hollister
417-337-5095

Joplin
417-623-3384

Springfield
417-866-2222

Topeka
785-862-8368

How to Roll an Inflatable

The key to a good roll is to fold the material neatly in to the middle of the inflatable.

1. Fold all material toward the middle of the inflatable and find the bottom seams.
2. Fold the inflatable like a large bed sheet. Be sure to tuck all colorful designs inside your folds to avoid contact with the ground.
3. Fold sides in 2 – 3 feet.
4. Tuck in any extra material. Leave ports out to allow air to escape as you roll.
5. Walk air out of the inflatable by walking on the inflatable toward the port (blower tube). Doing so pushes the air and allows it to escape.
6. Continue to fold inflatable from the outside in until folded layers overlap leaving a fold of 2 – 3 feet.
7. Begin rolling from the furthest point away from the port. Doing so helps remaining air to escape as you roll. Roll as tight as possible. Keep the roll lined up, tuck any extra material in, and do not allow any part of the roll to sag. Slack rolls are difficult to move. Take your time and roll it tight.
8. When the inflatable is near the end, tuck a rope or strap 2 –3 feet underneath the inflatable. This will be used to tie the roll. Doing so allows you to not lift the entire roll to tie off.
9. Tuck in ports, hoses and any extra material.
10. Tie off roll with the rope or strap.